



DELL CHROMEBOOK HANDOUTS

HOW TO POWER ON AND SHUTDOWN

1. If the Chromebook is charged. As soon as you open the lid it will power on.



2. Or press the power button to turn on and hold the power button to shut down.

