





Wall Plate



Plug VGA cable into Wall Plate marked #2

VGA IN VGA OUT



Back of the document camera




Back of the monitor



Plug VGA cable into Wall Plate marked #1

VGA OUTPUT VGA OUTPUT




Kramer VGA Splitter



VGA INPUT


Back of the computer



# 4

# 3

# 2



## CMS Wall Plate/Document Camera Hookup

- VGA Cable from the back of Computer goes into Kramer Box
- VGA Cable goes from a VGA Port on the Kramer Box into the Monitor
- VGA Cable from Kramer Box goes to the Wall Plate Port marked #1
- Document Camera goes to Wall Plate Port marked #2
- USB Extender with CAT5 goes to Wall Plate Port under the Coax Cable
- Cable Box plugs into the 3 RGA Ports on Wall Plate. Red goes into Red, Yellow into Yellow, and White into White.
- Sounds/Audio Cable (Green End) goes from Green Port on back of Computer to Wall Plate Port marked Audio#1
- There is also an Auxiliary Port that can be used for Audio as well marked Aux#2 on Wall Plate.

