



1. Back Panel Connectors
2. Expansion Slots
3. Voltage Switch (Set to 110)
4. Power Connector

1. Parallel Connector

2. PS/2 Mouse Connector

3. Link Integrity Light

Green — A good connection exists between a 10-Mbps network and the computer.

Orange — A good connection exists between a 100-Mbps network and the computer.

Yellow — A good connection exists between a 1-Gbps (or 1000-Mbps) network and the computer.

Off — The computer is not detecting a physical connection to the network.

4. Network Cable Connector

5. Network Activity Light

Flashes a yellow light when the computer is transmitting or receiving network data. A high volume of network traffic may make this light appear to be in a steady "on" state.

6. Line-in Connector

7. Line-out Connector (Plug Speakers into here)

8. Microphone Connector

9. USB Connectors

Plug keyboard, mouse, scanner, printer, etc if it's using a USB cable

10. PS/2 Keyboard Connector

11. Diagnostic Lights

12. Video Connector (monitor plugs into here)

13. Serial Connector (COM1)

