

1. Parallel Connector

2. Link Integrity Light

Green — A good connection exists between a 10-Mbps network and the computer.

Orange — A good connection exists between a 100-Mbps network and the computer.

Yellow — A good connection exists between a 1-Gbps (or 1000-Mbps) network and the computer.

Off — The computer is not detecting a physical connection to the network.

3. Network Cable Connector

4. Network Activity Light

Flashes a yellow light when the computer is transmitting or receiving network data. A high volume of network traffic may make this light appear to be in a steady "on" state.

5. Green Line-in Connector (Plug Speakers into here)


6. Line-out Connector (Microphone Connector)

7. USB Connectors

Plug keyboard, mouse, scanner, printer, etc if it's using a USB cable

8. Video Connector (monitor plugs into here)

9. Serial Connector (COM1)



1. Card Slots

2. Plug serial, USB, and other devices

3. Power Connector

4. Voltage Switch (Set to 110)

