



Your Plate might look different but it should have a VGA input



Back of the monitor



VGA IN VGA OUT

Back of the document camera

Kramer VGA Splitter



VGA OUTPUT

VGA OUTPUT

Back of the computer



VGA INPUT



Document Camera

Use the INT/EXT button OR CAMERA/PC button on top of the Doc Camera to switch between PC to Document Camera mode