



Your Plate might look different but it should have a VGA input



Back of the monitor



Back of the document camera

Kramer VGA Splitter



Back of the computer



VGA INPUT



Document Camera

Use the INT/EXT button OR CAMERA/PC button on top of the Doc Camera to switch between PC to Document Camera mode